

VOIP中关守和网关的配置 PDF转换可能丢失图片或格式，建议阅读原文

https://www.100test.com/kao_ti2020/269/2021_2022_VOIP_E4_B8_AD_E5_85_B3_c67_269714.htm 一、网关的配置dial-peer voice 111 potsdestination-pattern 0port 3/1/0 1、指定号码Gateway! 2、指定网关interface FastEthernet0/0ip addressduplex autospeed autoh323-gateway voip interfaceh323-gateway voip id GateKeeper ipaddr 0.0.0.0 1719h323-gateway voip h323-id syhoo@syhoo.com.cn 3、指定关守dial-peer voice 203 voipdestination-pattern 1.....session target ras! 4、指定VOIP映射，RAS方式dial-peer voice 203 voipdestination-pattern 1.....session target ras! 二、关守的配置gatekeeperzone local GateKeeper syhoo.com.cn 0.0.0.0gw-type-prefix 88#* gw ipaddr 0.0.0.0 1720gw-type-prefix 55#* gw ipaddr 0.0.0.0 1720no shutdown 所有地址都改为了0.0.0.0 100Test 下载频道开通，各类考试题目直接下载。详细请访问 www.100test.com